USER MANUAL

MI 404 **Free & Total Chlorine** and pH Meter



M Milwaukee

Dear Customer,

Thank you for choosing a Martini product. This manual will provide you with the necessary information for the correct use of the nstrument. Please read it carefully before using the meter. This instrument is in compliance with CEdirectives.

SPECIFICATIONS:

Range Resolution	0.00 to 5.00 mg/L Cl2Cl2 0.01 mg/L (0.00-3.50 mg/L); 0.10 mg/L (above 3.50 mg/
Precision	±0.04 mg/L @ 1.50 mg/L
Light Source	Tungsten lamp
Light Detector	Silicon Photocell and 525
Method	nm narrow band interfere- nce filter Adaptation of the USEPA method 330.5 and Standard Method 4500-CI G.
Environment	0 to 50 ℃ (32 to 122 °F);
	100% BH max.
Battery Type	1 x 9 volt
Auto-Shut off	After 10' of non-use
Dimensions	192 x 104 x 52 mm
	(7.5 x 4.1 x 2")
Weight	380 g
	9

MEASUREMENT PROCEDURE:

- 1. Turn the meter on by pressing ON/OFF. When the LCD displays "- - -", the meter is ready. 2• 10 ml
- 3• Fill the cuvet with 10 mL of unreacted sample, up to the mark, and replace the
- cap.4• Place the cuvet into the cu holder and ensure that the notch on the cap is positioned securely into the
- groove. 5• Press ZERO and "SIP" will
- blink on the display.
 /L) 6- After a few seconds the display will show "-0.0-". The meter is now zeroed and ready for measurement.



7• Remove the cuvet. For free chlorine measurement. add 3 drops of DPD 1 indicator and 3 drops of 8• DPD 2 buffer to an empty cuvet. Immediately add 10 mL of unreacted sample. Replace the cap and swirl gently.



- Immediately reinsert the cuvet into the 9• holder and ensure that the notch on the cap is positioned securely into the groove. 10• Press READ and "SIP" will blink during
- measurement.
- 11. The instrument directly displays concentration in mg/L of free chlorine.
- 12• Then, for total chlorine measurement, remove the cuvet and add to the reacted sample 3 drops of DPD 3. Replace the cap and swirl gently.



- 13. Reinsert the cuvet into the holder and ensure that the notch on the cap is positioned securely into the groove.
- 14. Wait for 2 minutes and 30 seconds then press READ and "SIP" will blink during measurement.
- 15• The instrument directly displays concentration in mg/L of total chlorine.

Interferences:

- Bromine (positive error)Chlorine dioxide (positive error)

Meth Envir Batte

- lodine (positive error)
- Oxidized Manganese (positive error)
- Chromium (positive error)
- Ozone (positive error)
- Alkalinity above 250 mg/L CaCO₃ or acidity above 150 mg/L CaCO₃ will not reliably develop the full amount of color or it may • rapidly fade. To resolve this, neutralize the sample with diluted HCl or NaOH.
- In case of water with hardness greater than 500 mg/L CaCO₃, shake the sample . for approximately 2' after adding the reagent.

GUIDE TO DISPLAY CODES:

This prompt appears for 1 second each time the instrument is turned on.
The dashes "" indicates that the meter is in a ready state and zeroing can be performed.
Sampling In Progress. Flashing "SIP" prompt appears each time the meter is performing a measurement.
"-0.0-", the meter is in a zeroed state and - 0.0 - measurement can beperformed.
The blinking "BAT" indicates that battery voltage is getting low and the battery needs to be replaced.

"-bA-", the battery is dead and	
must be replaced. Once this indication is displayed, the meter will lock up.	<u>- 68 -</u>
Change the battery and restart t	he meter.
"Conf", the meter has lost its configuration. Contact	[[onF
your dealer or the nearest	

Martini Customer Service Center.

ERROR MESSAGES

pr

On zero reading

•	Blinking "-0.0-" indicates	_
	that the zeroing procedure	ſ
	failed due to a low signal-	l
	to-noise ratio. In this case	_
	press ZERO again.	

- 0.0 -

L

Нι

"no L", the instrument	
cannot adjust the light level.	
Please check that the samp	le no
does not contain any debris.	

 "L Lo", there is not enough ligh 	t	
to perform a measurement.		
Please check the prepara-	L	Lo
tion of the zerocuvet.		

 "L Hi", there is too much light to perform a measure-L ment. Please check the preparation of the zero cuvet.

On sample reading

"-SA-", there is too much light for the sample measurement. Please check if the right sample cuvet is inserted.

"Inv", the sample and the zerocuvet are inverted.

 "ZErO", a zero reading was not taken. Follow the instruction in the measurement procedure for zeroing the meter.

٠	Under range. A blinking "0.00"
	indicates that the sample
	absorbs less light than the
	zero reference. Check the
	procedure and make sure you
	use the same cuvet for reference
	(zero) and measurement.


· A flashing value of the maximum concentration indicates an over range condition. The concentration of the sample is beyond the programmed range: dilute the sample

BATTERY REPLACEMENT

and re-run the test.

Battery replacement must only take place in a non-hazardous environment. Simply rotate the battery cover on the back of

the meter.



Inu

26-0

0.00-

5.00



Insert the battery and replace the cover.

ACCESSORIES:

MI504-100 Free & Total Chlorine (100 tests)

MI0001 Glass cuvets (2 pcs)

MI0002 Caps for cuvets (2 pcs) MI0003 Stoppers for cuvets (2 pcs) MI0004 Tissue for wipping cuvets (4 pcs) MI0005 9V battery (1 pc)

WARRANTY

WARRANTY This instrument is warranted against defects in materials and manufacturing for a period of two years from the date of purchase. If during this period the repair or replacement of parts is required, where the damage is not due to negligence or erroneous operation by the user, please return the metro to either distributor or our office in the original packing and the repair will be free of charge. Damages due to accidents, misuse, tampering or lack of prescribed maintenance are not covered.